

# Digital multimeter

08101  
KINCROME


## Operator's Instruction Manual



### WARNING

**READ AND UNDERSTAND THIS MANUAL BEFORE USING THE INSTRUMENT**

Failure to understand and comply with the **WARNING** and operating instructions can result in serious or fatal injuries and / or property damage.



### General Description

This instrument is a pocket sized 3-1/2 digit multimeter for measuring DC and AC voltage, DC current, resistance and performing transistor and diode test. Overload protection and low battery indication are provided.

### Front Panel Description

- 1 Display
- 2 Function and Range Switch
- 3 "10A" Jack
- 4 "V mA" Jack
- 5 "Common" Jack
- 6 Transistor Test Socket

### DC Voltage

Range	Resolution	Accuracy
200mV	0.1mV	$\pm 0.5\%$ of rdg $\pm 1D$
2000mV	1mV	$\pm 0.8\%$ of rdg $\pm 2D$
20V	10mV	$\pm 0.8\%$ of rdg $\pm 2D$
200V	0.1V	$\pm 0.8\%$ of rdg $\pm 2D$
600V	1V	$\pm 1.0\%$ of rdg $\pm 2D$

Overload Protection: 220V rms AC for 200mV range and 600VDC or 600V rms AC for other ranges.

### AC Voltage

Range	Resolution	Accuracy
200V	0.1V	$\pm 1.2\%$ of rdg $\pm 5D$
600V	1V	$\pm 1.5\%$ of rdg $\pm 5D$

Overload protection: 600VDC or 600V rms AC for all ranges.  
Response: Average responding, calibrated in rms of a sine wave.  
Frequency Range: 45Hz-450Hz

### DC Current

Range	Resolution	Accuracy
200 $\mu$ A	0.1 $\mu$ A	$\pm 1.0\%$ of rdg $\pm 2D$
2000 $\mu$ A	1 $\mu$ A	$\pm 1.0\%$ of rdg $\pm 2D$
20mA	0.01mA	$\pm 1.0\%$ of rdg $\pm 2D$
200mA	0.1mA	$\pm 1.0\%$ of rdg $\pm 2D$
10A	10mA	$\pm 2.0\%$ of rdg $\pm 3D$

Overload Protection: 500mA/250V fuse(10A range unfused)

### Resistance

Range	Resolution	Accuracy
200 $\Omega$ hm	0.1 $\Omega$ hm	$\pm 1.2\%$ of rdg $\pm 2D$
2000 $\Omega$ hm	1 $\Omega$ hm	$\pm 1.0\%$ of rdg $\pm 2D$
20k $\Omega$ hm	10 $\Omega$ hm	$\pm 1.0\%$ of rdg $\pm 2D$
200k $\Omega$ hm	100 $\Omega$ hm	$\pm 1.0\%$ of rdg $\pm 2D$
2000k $\Omega$ hm	1k $\Omega$ hm	$\pm 1.0\%$ of rdg $\pm 2D$

Maximum Open Circuit Voltage: 3.2V

Overload Protection: 250V rms AC on all range but 200  $\Omega$  Range.

1

2

3

4

### General Characteristics

Maximum Display: 1999 counts with automatic polarity indication  
Overrange Indication: "1" figure only in the display  
Maximum Common Mode Voltage: 600V DC/rms AC  
Temperature Ranges: Operating: 0°C to 40°C (32° F to 104° F)  
RH<80%

Storage: -10°C to 50°C (14° F to 122° F)

Temperature for Guaranteed Accuracy: 23°C to 5°C RH<75%  
Power Supply: 9V battery, NEDA 1604, 6F22 type or equivalent.  
Dimension: 126x70x25mm

Weight: Approx. 170g

This instrument complies with insulation category (over voltage category), CAT II 300V, CAT I 600V

### Operating Instruction

#### DC Voltage Measurement

- 1 Connect the red test lead to "V  $\Omega$  mA" Jack and the black test lead to "COM" Jack.
- 2 Set range switch at desired DCV range position. If the voltage to be measured is not known beforehand, set range switch to the highest range and then reduce it until satisfactory reading is obtained.
- 3 Connect test probes to device or load being measured.
- 4 Read voltage value on the LCD display along with the polarity of red lead connection.

#### AC Voltage Measurement

- 1 Connect the red test lead to "V  $\Omega$  mA" Jack and the black test lead to "COM" Jack.
- 2 Set range switch at desired ACV range position.
- 3 Connect test probes to device or load being measured.
- 4 Read voltage value on the LCD display.

### DC Current Measurement

- 1 Connect the red test lead to "V  $\Omega$  mA" Jack and the black test lead to "COM" Jack. (For measurement between 200mA and 10A, connect red lead to "10A" Jack)
- 2 Set range switch at desired DCA range position.
- 3 Open the circuit in which the current is to be measured, and connect test probes in series with the circuit.
- 4 Read current value on the LCD display along with the polarity of red lead connection.

### Resistance Measurement

- 1 Connect the red test lead to "V  $\Omega$  mA" Jack and the black test lead to "COM" Jack. (The polarity of red lead is positive "+")
- 2 Set range switch at desired resistance range position.
- 3 Connect test probes across the resistor to be measured and read the LCD display.
- 4 If the resistor being measured is connected to a circuit, turn off power and discharge all capacitors before measurement.

### Transistor Test

- 1 Set range switch at "hFE" position.
- 2 Determine whether the transistor under testing is NPN or PNP type and locate the emitter, base, collector leads. Insert the leads into proper holes of the hFE test socket on the front panel.
- 3 The meter will show the approximate hFE value at the condition of base current 10  $\mu$ A and Vce 3.0V.

### Diode Test

- 1 Connect the red test lead to "V  $\Omega$  mA" Jack and the black test lead to "COM" Jack.
- 2 Set range switch at  $\rightarrow$  position
- 3 Connect red probe to the anode of the diode to be tested and black probe to the cathode of the diode.

- 4 The approximate forward voltage drop of the diode will be displayed in mV. If the connection is reversed, only figure "1" will be shown.

### Battery and Fuse Replacement

- 1 If the sign "BAT" appears on the LCD display, it indicates that the battery should be replaced. Remove screws on the back cover and open the case. Replace the exhausted battery with a new one of the same type.
- 2 Fuse rarely need replacement and blow almost as a result of operator's error. Open the case as mentioned above and replace the blown fuse with the ratings of 0.5A/250V

### Safety Information

Follow all safety and operating instructions to ensure the meter is used safely and is kept in good condition.

### Preliminary

Safety can be guaranteed only with test leads supplied. If necessary, they must be replaced with the same electric ratings. Measuring leads must be in good conditions.

### During use

- 1 Never exceed the protection limit values indicated in the specifications for each range of measurement.
- 2 When the meter is linked to measurement circuit, do not touch the unused terminals.
- 3 Never use the meter to measure voltage that might exceed 500V above earth ground.

- 4 Always be careful when working with voltages above 60V DC or 30V AC rms. Keep fingers behind the probe barriers while measuring.
- 5 Do not perform resistance measurements on live circuits.
- 6 Never test AC current on this tester.

### Safety Symbols.



Important safety information.  
Refer to the operation manual.



Dangerous voltage may be present



Earth ground



Indicates the equipment complies with the requirements for double insulation



Indicates that the fuse must be replaced with one having the ratings indicated

### Maintenance

- 1 Before opening the case, always disconnect test leads from all energized circuits.
- 2 For continued protection against fire, replace fuse only with the specified voltage and current ratings: 0.5A / 250V (quick acting).
- 3 Never use abrasives or solvents on the meter, use only a fastener.
- 4 Do not use abrasives or solvents on the meter, use only a damp cloth and mild detergent to clean the meter.

### Accessories

1x Battery 9V 1604 6F22 or D06P  
1 set of Test Leads 1000V, 10A  
1x Operating Manual

5

6

7

8