

BATTERY TESTER ANALYZER 12V DC, 100 - 2000CCA, 30-220AH



KP8501 ED2/May 17

Table of Contents

Know Your Product	1	
General Safety Instructions	2 -	3
Operation	3 -	10
Installing CD Drivers	10	
Warranty	14	



Know Your Product

- 1. Up Key
- 2. Down Key
- Exit Key 3.
- 4. Enter Key
- 5. Mini-USB Socket (Side of Product)
- 6. **Digital Display**
- BLACK (-) Negative Battery Clamp 7.
- RED (+) Positive Battery Clamp 8.
- 9. CD (Operation Software)
- 10. USB to mini USB Cable

Specifications

Part No	KP8501
Battery Test Capability	12V DC, 100 - 2000CCA/30-220Ah
Suitable For	Wide Variety of 12 Volt Batteries
Power	Via Battery Being Tested
Operating Temperature	0 to 50°C (-32 to 122 F°)
Storage Temperature	-20 to 70°C (-4 to 158 F°)
Cable Clamps	Heavy Duty Insulated
Display	LCD, Backlit
Length x Width x Height	110mm x 70mm x 16mm
Weight	250g

9

GENERAL SAFETY WARNINGS

NGROME



Save all warnings and instructions for future reference. WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

General Safety Warnings

- 1. The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur.
- 2. Common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

Work Area

- 1. Operate in a safe work environment. Keep your work area clean and well lit.
- 2. Keep anyone not wearing the appropriate safety equipment away from the work area.

Note: Minimize distractions in the work environment.

- **3.** Distractions can cause you to lose control of the tool.
- 4. When connecting the battery tester analyzer cables to the battery, avoid creating sparks; especially when the battery is being charged. Explosive gases are created during charging. Sparking could also damage the vehicle electrical system.
- 5. Always lock up tools and keep them out of the reach of children

Personal Safety

- 1. Wear ANSI-approved safety goggles during set up and use of the Battery Tester.
- 2. Test in a well ventilated area. Explosive gases may be produced during testing. Do not smoke, cause sparks, or strike matches near the battery when testing.
- **3.** Protective, electrically non-conductive clothes and non-skid footwear are recommended when working. Wear steel-toed boots to prevent injury from falling objects.
- **4.** Refer to the user manual of the battery being tested for testing instructions and precautions prior to using the battery tester analyzer.
- 5. Do not connect in reverse polarity.
- **6.** Use this product in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of this product for operations different from those intended could result in a hazardous situation.
- 7. This product is not a toy. Keep it out of reach of children.
- 8. Maintain labels and nameplates on the unit. These carry important safety information. If unreadable or missing, contact Kincrome Tools for a replacement.
- 9. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure. Caution is necessary when near coil, spark plug cables, or distributor of running engine. Engine should be off during distributor adjustment.
- 10. Undercharged lead-acid batteries will freeze during cold weather. Do not test or charge a frozen battery.
- **11.** Do not smoke or have open flames near the battery.
- 12. Never remove battery load tester clamps while testing.
- 13. Ensure automatic vehicles are in park with the handbrake on before starting the engine.
- 14. Ensure manual vehicles are in neutral with the handbrake on before starting the engine.
- **15.** Road Safety Road Rules 2009 penalty code 2135, it is illegal to leave "motor vehicle unattended with keys in ignition, motor running, brakes not secured or doors unlocked.

Risk of Electric Shock

- 1. Never touch the clamps and the terminals with wet hands.
- 1. Do not pull the clamps from the terminals by pulling on the clamp cables.
- 2. Check the clamp leads for damage before every use.
- 3. Be certain of the test battery polarity before connecting the battery tester analyzer clamps (7 & 8). The RED (+) positive battery clamp (8) goes to the positive terminal of the battery. The BLACK (-) negative battery clamp (7) goes to the negative terminal of the battery. Reversing the battery tester analyzer battery clamps (7 & 8) on the battery may damage the battery tester analyzer.
- 4. Do not drop the battery tester analyzer as it may affect proper operation.
- 5. Do not smoke or have open flames near the battery.
- **6.** The warnings and precautions discussed in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Tester Use and Care Instructions

- 1. This battery tester analyzer was designed for specific functions.
- 2. DO NOT modify or alter the battery tester analyzer, all parts and accessories are designed with built-in safety features that may be compromised if altered.
- 3. DO NOT use the battery tester analyzer in a way for which it was not designed.

Operation

1. Connecting the Tester

Before testing make sure the battery terminals are really clean as grease and dust could lead to errors in the test results. If the battery is still fitted to a motor vehicle, make sure that all the electronics are turned OFF, and that the ignition is turned OFF. The **RED** (+) Positive Battery Clamp (8) is connected to the (+) positive battery terminal and the **BLACK** (-) Negative Battery Clamp (7) is connected to the (-) negative battery terminal. Ensure that the clamps have a firm, secure grip on the battery terminals. If the tester has a poor connection it will not be able to start-up. If this happens clean the battery terminals

2. Initial Product Setup

The tester allows you to make the following adjustments and settings:

- 1. Language: Selects required language.
- 2. Contrast adjustment: Adjusts the contrast of the LCD display.
- 3. Tool information: The tester show the software and hardware versions.

Note: The Battery Tester must be connected to your battery prior to any settings or product outputs can be made.

3. Change the Language

NCROMEC

- 1. Connect tester as specified "Connecting the Tester".
- 2. Press Enter Key (4) to navigate to Main Menu.
- 3. Press Down Key (2) to navigate to 6. System Setup, press Enter Key (4) (Fig 2).
- System Setup; Press the Down Key (2) to navigate to Select Language, press Enter Key (4) (Fig. 3). 4.
- 5. Using the Down Key (2), select required Language, press Enter Key (4).

Note: Once Enter Key (4) has been pressed, the system will return to the start-up screen.

Main Menu		Language
1. Quick Test		1.English
2. Battery in Vehicle		2. French
3. Out of Vehicle	System Setup	3. German
4. Review Data	1. Language	4. Spanish
5. Print Data	2. Contrast	5. Italian
6. System Setup	3. Tool Information	6 . Polish
Fig. 2	 Fig. 3	Fig. 4

4. Change the Contrast

- 1. Connect tester as specified "Connecting the Tester" (Page 3).
- 2. Press the Enter Key (4) to navigate to the Main Menu.
- 3. Press the Down Key (2) to navigate to 6. System Setup, press the Enter Key (4) (Fig 2).
- 4. System Setup; press the Down Key (2) to navigate to 2. Contrast, press Enter Key (4) (Fig. 3).
- Using the Up Key (1) and Down Key (2) to increase or decrease the contrast, 5. Enter Key (4) (Fig.5).

Note: Once the Enter Key (4) has been pressed, the system will return to the start-up screen.

5. View Tool Information

- Connect tester as specified "Connecting the Tester" (Page 3). 1.
- Press Enter Key (4) to navigate to Main Menu. 2.
- Press Down Key (2) to navigate to 6. System Setup, press Enter Key (4) (Fig 2). 3.
- 4. System Setup; Press Down Key (2) to navigate to 3. Tool Information, press Enter Key (4) (Fig 3).
- To return to the Main Menu (Fig. 2) press Exit Key (3). 5.

6. Quick Test

It can test the battery status, including voltage, CCA, electronic resistance, rated CCA, charging value, healthy value and testing result in ONE second. Once you input the AH value- (battery rated capacity), which is marked on the label of the battery being tested.

Note: When checking AH rated batteries

- Connect tester as specified "Connecting the Tester" on Page 3. 1.
- Press Enter Key (4) to navigate to Main Menu. 2.
- 3. Ensuring the 1. Quick Test (Fig.2) is highlighted press the Enter Key (4) to confirm.
- 4. Using the Up Key (1) / Down Key (2) input the rated battery capacity—xx AH, Refer to the battery rating label of the battery being tested and input the AH battery value (Fig. 7).
- 5. Then press the Enter Key (4). The battery test results will show as per Examples on page 5.





Fig. 6

Input AH Value

50 A-H

Please input the A-HR Value from the Label on the Battery being tested

Fig. 7

7. Battery Test Result Examples

Good Battery (Fig. 8)

The battery is in good working condition.

Healthy: 96%	490CCA
Charge: 98%	12.64V
Internal R=6.1m Ω	
Rated: 500A	
GOOD BATTERY	

Fig. 8

Healthy: 78%	490CCA
Charge: 30%	12.20V
Internal R=7.2m Ω	
Rated: 500A	
GOOD, RECHARGE	

Fig. 9

Healthy: 46%	490CCA
Charge: 80%	12.68V
Internal R=18.1m Ω	
Rated: 500A	
REPLACE	

Fig. 10

Healthy: 0%	0CCA
Charge: 20%	10.64V
Internal R=45.2m Ω	
Rated: 500A	
BAD CELL, REPLACE	

Fig. 11

Healthy: 39%	310CCA	
Charge: 20%	12.08V	
Internal R=30.1m Ω		
Rated: 500A		
CHARGE - RETEST		

Fig. 12

Good, Recharge (Fig. 9)

Good battery but low current, recharge before using.

Replace (Fig. 10)

The battery is near to or already reached the end of it's useful life. Replace battery.

Bad Cell, Replace (Fig. 11)

Battery internal damage, bad cell or short circuit, replace battery.

Charge - Retest (Fig. 12)

Unstable battery, recharge and retest to avoid error. If same test result appears after recharge and retest, the battery is deemed as faulty, replace the battery.

8. Battery In-Vehicle or Battery Out-Of-Vehicle Tests

Battery in vehicle means the battery is connected to the vehicles battery cables / terminals or vehicles accessories. Out of Vehicle means the battery is not connected to the vehicles battery cables / terminals.

A. Battery in Vehicle

INCROME C

- 1. Connect tester as specified "Connecting the Tester" (Page 3).
- 2. Press Enter Key (4) to navigate to Main Menu.
- Press Up Key (1) / Down Key (2) to navigate to" 2. Battery in Vehicle" (Fig. 13) and press Enter Key (4), it will enter "Test In Vehicle" menu (Fig. 14).
- 4. Choose one of the test as shown in Fig. 14 and press Enter Key [4].

B. Battery Test

The battery tester will test each battery according to the selected test standard and rating.

- 1. Press Enter Key (4) on "1. Battery Test", the "check surface charge" prompt screen will display a sequence of instruction (Fig.15), which you are required to follow before proceeding.
- 2. Once you have turned your headlights OFF, press the Enter Key (4).

C. Select Battery Type

- 1. The tester will prompt to select battery type (Fig. 16). Press Up Key (1) / Down Key (2) to select battery type (as displayed on the battery rating label), then press Enter Key (4) to confirm.
- Press Up Key (1) / Down Key (2) to select the correct testing standard (Fig.17) as specified on the battery rating label. Press Enter Key (4) to select testing standard. Refer to the Battery System Standard Description page 13.
- Press Up Key (1) / Down Key (2) to select the battery capacity rating (Fig. 18) as displayed on the battery rating label. Press the Enter Key (4).

Note: A single Press Up Key (1) / Down Key (2) will increase / decrease by 5Amp intervals, Press and hold Up Key (1) / Down Key (2) will increase /decrease the rating rapidly.

- The tester performs the test, It takes approximately 5-10 seconds to display the battery test result.
- 5. Compare to the 'Battery Test Result Examples' on page 5.
- 6. Press the Exit Key (3) to return to the start-up screen.

D. Cranking Test

- 1. Connect tester as specified "Connecting the Tester" on Page 3.
- 2. Press Enter Key (4) to navigate to Main Menu.
- Press Up Key (1) / Down Key (2) to select the battery location, "2. Battery in Vehicle" then press Enter Key (4) to confirm (Fig14).
- "Start Engine" is prompted (Fig.19), Start the vehicle and the tester will perform the cranking test and display the result (Fig 20, 21 & 22) on Page 7.
- 5. Normally a cranking voltage value lower than 9.6V is regarded as abnormal, click the Enter Key (4).
- 6. Test result includes cranking voltage and cranking time.

7. After testing finished Press the Exit Key (3) to return to the start-up screen. **Note:** If this is the last test, turn off vehicle engine.

1. Quick Test

2. Battery in Vehicle

3. Out of Vehicle

4. Review Data

5. Print Data

6. System Setup

Fig. 13

Test In Vehicle

1. Battery Test

2. Cranking Test

3. Charging Test

Fig. 14

Battery Test

1. Check surface charge.

Turn lights ON

2. Turn headlights on for

approx. 10 seconds

3. Turn lights OFF

Fig. 15

 Battery Type

 1. Regular Flooded

 2. AGM Flat Plate

 3. AGM Spiral

 4. GEL

 5. EFB

Fig. 16

Select Input CCA

Fig. 17



Fig. 18

Cranking Test Start Engine

Cranking Test Results

ROME

Cranking Test	
RPM Detected	

M Delected

Fig. 20

E. Charging Test

- 1. Connect tester as specified "Connecting the Tester".
- 2. Press Enter Key (4) to navigate to Main Menu.
- Press Up Key (1) / Down Key (2) to select "2. Battery in Vehicle" then press Enter Key (4) to confirm.

Cranking Test

Time Cranking 780ms

Normal

10.13V

Fig. 21

- 4. Start the Vehicle's engine.
- 5. Press Up Key (1) / Down Key (2) to select "3. Charging Test" (Fig. 23).
- 6. Press the Enter Key (4) to start the charging test.

Caution: Do not shut down the engine during the test. Ensure all electrical accessories and devices remain in the OFF state. Turning ON/OFF any electrical accessories in the vehicle during the test will affect the accuracy of the test result.

Tester will do the following tests in a sequence:

1. For "Ripple Test", tester will display the real time ripple and meanwhile, shows ripple volt and charging volt values at the bottom line (Fig. 24).

Note: It takes approx. 5-10 seconds to complete ripple test.

- After the ripple test, tester will automatically start the Loaded Voltage Test (Fig. 24). The tester prompts the Operator to "Increase RPM to 2500r/min and keep it 5 seconds" (Fig 25), depress accelerator to increase engine revs.
- **3.** Tester starts the Charging Volt Test, once the battery voltage is increase is detected (Fig. 26).
- After the test is finished, the tester will displays the test results and battery charging state (No-Output, Charging Low, Charging Normal or Charging High)[Fig. 28].

Note: The Tester will try 3 times to detect the Battery Voltage increase, if an increase is not detected the tester will skip the rev detection test, and display the test result from the ripple and loaded tests.

If the battery is not receiving a charge the tester displays "No Volt Output". Refer to Page 8 for explanation of charging states :

5. Press the Exit Key (3) to return to the start-up screen.

Cranking Test	
Time	1020ms
Cranking	Low
Replace	10.13V











Fig. 25



Charging Test	
Testing	



Charging Test		
Loaded	14.16V	
Unloaded	14.39V	
Ripple 15mV		
Charging Normal		

Charging Test Results

NGROME

Charging Volt	
Normal	Charging system shows the alternator output is normal, no problem has been detected.
Low	 Check if alternators' drive belt is slipping or broken. Adjust or replace as required. Check the connections between alternator and battery to ensure there are no loose or damaged connections. Tighten and replace as required. If both the drive belt and connections are in good condition, follow the vehicles' manufacturer's troubleshooting to eliminate an alternator fault.
High	 Most vehicle alternators use an internal regulator, the complete alternator assembly will be required to be replaced (Some old cars use external regulator, which can be replaced). The acceptable high voltage limit of the regulator is a maximum of 14.7±0.5V. If charging voltage is too high, it will overcharge the battery. The battery life maybe shortened.
No Volt Output	 The RPM did not each 2500r/min. Check to see if the alternators' drive belt is slipping or broken. Adjust or replace as required. Check the connections between alternator and battery to ensure there are NO loose or damaged connections. Clean, tighten or replace as required. Alternator regulator fault, check and replace as required.
Diode Test	 The Ripple Test will determine whether the diode(s) are functioning as designed. When Ripple Test Voltage is too high, it indicates that at least one diode is damaged. Check and replace any faulty diode(s).

F. Out of Vehicle

- 1. Connect tester as specified in "Connecting the Tester" on Page 3.
- 2. Press Enter Key (4) to navigate to Main Menu.
- **3.** Press Up Key (1) / Down Key (2) to navigate to "3. Out of Vehicle", then press Enter Key (4) to confirm (Fig. 29).
- 4. The tester will prompt to select battery type (Fig 30. Press Up Key (1) / Down Key (2) to select battery type (as displayed on the battery rating label), then press Enter Key (4) to confirm.
- Press Up Key (1) / Down Key (2) to select the correct test standard (Fig.31) as specified on the battery rating label. Press Enter Key (4) to select test standard. Refer to the Battery System Standard Description page 13.
- Press Up Key (1) / Down Key (2) to select the correct rated battery capacity as displayed on the battery rating label. Press the Enter Key (4).
 Note: A Single Press Up Key (1) / Down Key (2) will increase/decrease by 5Amp intervals, Press and hold Up Key (1) / Down Key (2) will increases/Decrease the rating rapidly.
- 7. The test is preformed, It takes approximately 5-10 seconds to display the battery test result.
- 8. Refer to 'Battery Test Result Examples' on page 5 for battery condition.
- 9. Press the Exit Key (3) to return to the start-up screen.



1. Quick Test 2. Battery in Vehicle

2. Battery in vehicle

3. Out of Vehicle

4. Review Data

5. Print Data

6. System Setup





Fig. 30

Setting Rating	
500	
CCA	

9. Review Data

RIN

- 1. Connect tester as specified "Connecting the Tester" on Page 3.
- 2. Press Enter Key (4) to navigate to Main Menu.
- Press Up Key (1) / Down Key (2) to navigate to "4. Review Data" (Fig. 32).
 Note: This will only display the last test performed
- 4. Refer to the below examples for battery conditions.

Main Menu
1. Quick Test
2. Battery in Vehicle
3. Out of Vehicle
4. Review Data
5. Print Data
6. System Setup

Healthy: 96%	490CCA	
Charge: 98%	12.64V	
Internal R=	6.1m Ω	
Rated:	500A	
GOOD BATTERY		

Healthy: 46%	490CCA		
Charge: 80%	12.68V		
Internal R=	18.1m Ω		
Rated: 500A			
REPLACE			

Healthy: 39%	310CCA	
Charge: 20%	12.08V	
Internal R=	30.1m Ω	
Rated: 500A		
CHARGE - RETEST		

Healthy: 78%	490CCA	
Charge: 30%	12.20V	
Internal R=	7.2m Ω	
Rated:	500A	
GOOD, RE	CHARGE	

Healthy: 0%	0CCA
Charge: 20%	10.64V
Internal R=	45.2m Ω
Rated: 500A	
BAD CELL,	REPLACE

10. Installing KP8501 Drivers

RUM

- 1. Insert the CD supplied with the tester and when the Autoplay select "Open folder to view files" (Fig 32).
- 2. Double click on Software and USB driver folder (Fig. 33)
- 3. Double Click "Battery Tester" Folder (Fig. 34)
- 4. Double Click the "KP8501 Battery Tester" Folder (Fig. 35)
- 5. Double Click the USB Driver Folder (Fig.36)
- 6. Double Click the installation file and follow the prompts..

stall or run program from your media Run Install.cse Publisher not specified menal externs	🔒 ADOBE	13/05/2014 2:22 PM 13/05/2014 2:22 PM	File folder File folder	Battery tester Car trip computer EPB tool	30/03/2016 3:05 PM File fo 30/03/2016 3:03 PM File fo 13/05/2014 2:22 PM File fo
Open folder to view files	Annuals	30/03/2016 3:05 PM 30/03/2016 3:06 PM	File folder File folder	General scan tool GBDB2JOBD auto scan tool	8/03/2016 8:06 PM File fo 30/03/2016 2:51 PM File fo
using Dropbox using Dropbox more AwtoPlay options in Control Panel	المعالمين ا المعالمين المعالمين ال	21/04/2008 7:00 AM 26/04/2010 1:34 PM	Setup Informatio Application	 Oil reset tool Professional auto scan tool VAG auto scan tool for Audi and Volksw. 	30/03/2016 3:00 PM File fo 30/03/2016 3:08 PM File fo 8/03/2016 8:03 PM File fo
Fig. 32	Fi	g. 33		Fig.	34

15/05/2017 4:05 PM

11. Print Data

1. Navigate into "KP8501 Battery Tester Folder" (Fig.35) as described in "Installing KP8501 Drivers"

Fig. 35

- 2. Double Click Print Software folder (Fig 36).
- Double Click "PrintCOM" application.
 Note: This program can run from the CD, or copied to your local computer hard drive.

KP8501 Battery Teste

- 4. Before proceeding any further, press the clear button to remove any information displayed (Fig 32).
- 5. Using the USB to USB-Mini cable (supplied) connect the tester to your computer.
- When the tester is connected, the software should automatically detect the tester COM port No, if not select COM port manually.
- 7. Press Enter Key (4) to navigate to Main Menu.
- Press Up Key (1) / Down Key (2) to navigate to "5. Print Data" (Fig. 33) and press Enter Key (4) to export the data.

Note: The tester will return to the Main Menu (Fig. 33) after export is completed.

- 9. Once the data is transferred to the computer, the print software will show testing results (Fig. 34).
- 10. In the Print COM program click the print button and follow your computer printing procedure.

Print	Clear	COM1 Connected OK ·	
9600bps			
RECOXODERACOS	láióúáéÑAç		
910 SAE J	1850 VPW		
1			
Vehicle Info.			
Not Supported	Or Stored N	o Data.	
1			



NwCOM v1.5.0621	Description of the local division of the loc	(o) illi
Print Clear	COH5-Convected OK ·	
Battery Test		
Sealthy: 1004 2200CA		
Charge: 914 12.557		
Internal E= 13.34m		
Reted: 220 A		
Jelecu Input: 00A		
GOOD BATTERY		
Crenking Test		
Cracking Time \$14m2		
Cranking Voltage MORNAL		
9.947		
Charging Test Londed 13.957		
Unloaded 14.21V		
Ripple 25mV		
CHARGERS NORMAL		

Fig. 32



Fig. 34

12. Battery System Standard Description

ROME

1. The battery tester analyzer will test each battery according to the selected system and rating.

CCA	Cold Cranking Amps, specified by SAE&BCI, most frequently used value for starting battery at 0°F [-18°C]
BCI	Battery Council International standard
CA	Cranking Amps standard, effective starting current value at 0°C
МСА	Marine Cranking Amps standard, effective starting current value at 0°C.
JIS	Japan Industrial Standard, displayed on the battery as combination of the numbers and letters, e.g. 55D23,80D26.
DIN	German Auto Industry Committee Standard
IEC	Internal Electro technical Commission Standard
EN	European Automobile Industry Association Standard
SAE	Society of Automotive Engineers Standard
GB	China National Standard

13. Measuring Range

The Battery Tester can perform test on batteries rated within 100-2000CCA/30Ah-220AH

Measure Standard	Measure Range
CCA	100-2000
BCI	100-2000
СА	100-2000
MCA	100-2000
JIS	26A17245H52
DIN	100-1400
IEC	100-1400
EN	100-2000
SAE	100-2000
GB	100-1400



Spare Parts

No spare parts are available for this product. Contact Kincrome Customer Service for information regarding spares /



replacement of this product. Office Contact Details

Phone: 1300 657 528



Fax: 1300 556 005

Email: enquiries@kincrome.com.au

Website: www.kincrome.com.au



Caring For The Environment

Ð

When a tool is no longer usable it should not be disposed of with household waste, but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.

Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

Also Available

Battery Load Tester - 6 or 12V <100A

- Test 6V or 12V batteries, test the charging system, analyze battery condition, test starter motor on your vehicle all with one tool
- Test standard lead acid vehicle batteries

KP1460

Carbon Pile Load Tester - 12V <500A

- Test 12V DC batteries, alternators, regulators & starters
- Test batteries up to 160Ah/1000CCA
- 500 Amp adjustable load
- Large colour coded display meters
- Metal, powder coated surface

KP1461

Diagnostic Scan Tool OBD2 - CAN Enabled

- Works with MOST 1996 and later OBD2 compliant vehicles
- Supports all OBD2 protocols including the newer (CAN) Controller Area Network
- Reads your (DTC) Diagnostic Trouble Codes for identification
- Turns off check engine light (MIL)
- Erases (DTC) trouble codes and resets the OBD2 system
- Includes a user manual with a comprehensive list of the most current trouble codes

K8410







Also Available Cont.

NGROME

Booster Cables

Standard 100A 12V DC

- Suits 4 Cylinder Petrol Engines
- Heavy Duty Terminal Clamps .

KP1451

Standard 200A 12V DC

- Suits 4, 6 Cylinder Petrol Engines
- Heavy Duty Terminal Clamps .
- **KP1452**

Premium 400A 12V / 24V DC

- . Suits 4, 6 & 8 Cylinder Petrol Engines
- Heavy Duty Terminal Clamps

KP1453

Premium 600A 12V / 24V DC

- Suits Diesel & Petrol Engines .
- Extra Heavy Duty Terminal Clamps
- Copper Clamp Bridges

KP1454

Ultimate 800A 12V / 24V DC

- Suits Commercial Vehicles
- Extra Heavy Duty Terminal Clamps
- Copper Clamp Bridges

KP1455

Ultimate 1000A 12V / 24V DC

- Suits Construction & Earth Moving
- Extra Heavy Duty Terminal Clamps
- **Copper Clamp Bridges**

KP1456

KP1453, KP1454, KP1455 & KP1456 Include



INTELLI-CHECK II Alternator Check **Reverse Polarity Indicator Battery Condition Indicator**

3.5m Cable Length

•

- Intelli Check II Feature
- 3.5m Cable Length Intelli Check II Feature

6m Cable Length

Intelli Check II Feature









- 2.5m Cable Length

- 2.5m Cable Length
- 3m Cable Length ٠
 - Intelli Check II Feature



Notes



Warranty given by Kincrome Australia Pty Ltd of 3 Lakeview Drive, Caribbean Park, Scoresby, Victoria [Tel 1300 657 528]. The applicable warranty period II2 months] commences on the date that the product is purchased. If this product has materials or workmanship defects (other than defects caused by abnormal or non warranted use) you can, at your cost, send the product to place of purchase, an authorised Kincrome service agent or one of Kincromes addresses for repair or replacement. Your rights under this warranty are in addition to any other rights you have under the Australian Consumer Law or other applicable laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or replaced if the goods fail to be of acceptable quality and the failure does not amage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please visit www.kincrome.com.au or call us. Due to minor changes in design or manufacture, the product you purchase may sometimes differ from the one shown on the packaging.



www.kincrome.com.au